

READ AND SAVE THESE INSTRUCTIONS



OPERATING INSTRUCTIONS

Evaporative humidifier

PureHum 1000 Pro



PLEASE READ THESE OPERATING INSTRUCTIONS CAREFULLY BEFORE STARTING ANY WORK!

Information on the operating instructions

These instructions enable the safe and efficient use of the evaporative humidifier PureHum 1000 Pro. The instructions are part of the humidifier and must be kept in the immediate vicinity of the unit and accessible at all times.

The user must have carefully read and understood these instructions before starting any work. The basic prerequisite for safe working is compliance with all the safety instructions and instructions for action given in this manual.

In addition, the local accident prevention regulations and general safety regulations for the area of use of the humidifier apply.

Due to continuous further developments, illustrations, functional steps and technical data may deviate slightly. Original operating instructions.

Copyright protection

The contents of this manual are protected by copyright. Their use is permitted within the scope of use of the unit. Any other use is not permitted without the written consent of Condair Ltd.

Customer service

Address Condair Ltd.
 2740 Fenton Road
 Ottawa, Ontario K1T3T7
 CANADA

Phone +1 866.667.8321

E-mail na.info@condair.com

Web www.condair.com

You can find your local contact at: www.condairgroup.com/find-your-local-condair-distributor

Information about this operating manual

This operating manual allows the safe and efficient use of the Evaporation Humidifier PureHum 1000 Pro. This operating manual is an integral part of the humidifier and must be stored, readily accessible for the personnel, in close proximity of the device. This operating manual must be carefully read by the user prior to starting any work. The prerequisite for safe working is to comply with all safety and procedural instructions specified in this operating manual. The local accident prevention regulations and the general safety regulations for the application area of the humidifier also apply. The illustrations in this operating manual are intended for the basic understanding and can deviate from the actual design.

FCC compliance statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio technician for help.

Table of contents

1. The PureHum 1000 Pro evaporative humidifier	5
1.1 General overview	5
1.2 Touchdisplay.....	6
1.3 Radio humidity transmitter	6
1.4 Functional description	6
2. Security	7
2.1 Symbols in this manual Safety instructions	7
2.2 Intended Use.....	8
2.3 Symbols on the device.....	9
2.4 Safety and Dangers	9
2.5 Responsibility of the operator	11
2.6 Personnel requirements.....	11
2.7 Environmental protection.....	12
3. Transport and Storage	13
3.1 Safety instructions for transport and storage.....	13
3.2 Symbols on the packaging	13
3.3 Storage of the packages.....	13
3.4 Transport inspection	13
3.5 Storage when not in use.....	14
3.6 Transport humidifier	14
4. Commissioning.....	15
4.1 Safety instructions for initial commissioning	15
4.2 Requirements for the site.....	15
4.3 Putting the humidifier into operation for the first time	15
5. Operating the humidifier	18
5.1 Displays on the device	18
5.2 Switching on and off Switching on.....	20
5.3 Filling the water tank Improper filling.....	21
5.4 Set the desired humidity	21
5.5 Setting the blower level	22
5.6 Radio humidity transmitter	22
5.7 Change menu settings	24
5.8 Operating modes.....	26
5.8.1 Air purifier mode	26
5.8.2 Humidifier mode.....	26
5.8.3 Operating modes fixed value & timer.....	27
6. Clean humidifier and maintain	27
6.1 Safety instructions for cleaning and care	27
6.2 Cleaning schedule.....	28
6.3 Cleaning work	28
6.3.1 Monthly Cleaning.....	28
6.3.2 Change filter	30
6.3.2.1 Change evaporation	30
6.3.2.2 Change cleaning filter	32
6.3.2.3 Insert activated charcoal cleaning filter	33
6.3.3 Cleaning the water	34
6.3.4 Descaling the appliance Preparation	35
7. Recognize faults and rectify them	38
7.1 Safety instructions for Troubleshooting.....	38
7.2 Fault indication.....	38
7.3 Error table.....	40
7.4 Correct error.....	41
7.4.1 Replace pump	41
7.4.2 Replace blower Remove old blower	43
8. Accessories.....	45
8.1 UV disinfection and lime conversion cartridge	45
8.1.1 UV disinfection and lime conversion cartridge cleaning.....	46
8.1.2 Replace UV lamp	48
8.2 Automatic Water supply	50
8.3 Automatic Flushing device.....	51
8.4 Safety catch basin	52
8.5 Safety water sensor.....	52
8.6 External Water monitor	52
8.7 Wlan/Wifi	53
8.7.1 Wlan/Wifi Setup	53
8.7.2 Condair PureHum App	55
8.7.3 Activate Condair WLAN / reset network settings.....	56
9. Spare parts	57
9.1 Filter overview	57
10. Dispose of humidifier	57
11. Technical Data.....	57
11.1 Dimensions and Weight.....	57
11.2 Connection values	58
11.3 Operating conditions	58
Appendix.....	58
Spare parts list	59

1. The PureHum 1000 Pro evaporative humidifier

1.1 General overview

1. Filling opening (under glass plate)
2. Air outlet
3. Touch display (under glass plate)
4. Air inlet opening
5. Water tank




Fig. 1.1.1: Evaporative humidifier PureHum 1000 Pro

Scope of delivery




Fig. 1.1.2: Scope of

Pos.	Number	Designation
Fig. 1.1.1	1	Evaporative Humidifier PureHum 1000 Pro
Fig. 1.1.2 (1)	1	Radio humidity transmitter
Fig. 1.1.2 (2)	1	Cleaning brush
	1	Operating instructions



The batteries required for the radio humidity transmitter are not part of the scope of delivery! Two AA batteries are required.

1.2 Touchdisplay

The touch display provides information about the status of the unit. Among other things, it provides information about the current water level, the current actual and target humidity values and any faults in the unit.

All settings on the unit can be managed via the touch display. A smartphone connection via app is also possible.

Pos.	Explanation
1	Operating mode (humidifier/air purifier)
2	Time HH:MM
3	Date (Day, DD.MM.YYYY)
4	Current fan speed ⇄ speed menu setting
5	Water level indicator
6	Setpoint & actual humidity in % ⇄ Setpoint humidity menu
7	Room temperature
8	Display next water change/ next cleaning
9	Display next filter change
10	Off and on switch: ⇄ Submenu: <ul style="list-style-type: none"> • Switch off • System settings • Lock touch display
11	Display Notes & Error Messages
12	⇄ Menu




Fig. 1.2.1: Touch display

1.3 Radio humidity transmitter

The radio humidity transmitter controls the humidifier automatically. It measures the current air humidity and sends the value to the humidifier at three-minute intervals or if the humidity changes by more than 2 %. In automatic mode, the fan speed is regulated according to the set humidity value.



Fig. 1.3.1: Radio humidity

1.4 Functional description

The PureHum 1000 Pro humidifier works according to the natural principle of evaporation. A water pump continuously conveys water from the water tank (3) into the oval water channel (2). The water seeps through the drain holes inside the trough and moistens the evaporation filter (4). A fan (1) inside the humidifier draws in the air. This flows through the evaporation filter and is cleaned and humidified in the process. The humidified air is then released back into the room through the air outlet opening on the top (arrow). The humidifier is filled manually via the filling opening under the glass plate. Optionally, the unit can also be connected to the local water supply. In this case, the humidifier is filled automatically and manual filling is not necessary (↪ chapter „8. Accessories" on page 44). You have the option of operating the unit either as an air humidifier or air purifier. The units are delivered from the factory in humidifier mode. In air purifier mode, the unit is operated without water. The fan always runs and the water pump is deactivated (↪ chapter 5.8 "Operating modes").



Abb. 1.4.1: Operating principle

2. Security

This section provides an overview of all important safety aspects for the protection of persons and for safe and trouble-free operation. Further task-related safety instructions are contained in the sections on the individual life phases.

2.1 Symbols in this manual

Safety instructions

Safety instructions in this manual are marked by symbols. The safety instructions are introduced by signal words, expressing the extent of the hazard.

DANGER

This combination of symbol and signal word indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

This combination of symbol and signal word indicates a possibly dangerous situation which can lead to death or serious injury if not avoided.

CAUTION

This combination of symbol and signal word indicates a potentially hazardous situation which, if not avoided, may result in minor or slight injury.

NOTICE

This combination of symbol and signal word indicates a potentially hazardous situation which, if not avoided, may result in environmental and property damage.

Safety instructions in handling instructions

Safety instructions can refer to specific, individual instructions for action. Such safety instructions are embedded in the handling instructions so that they do not interrupt the flow of reading when performing the action. The signal words described above are used.

Example:

1. Loosen the screw.

2.

CAUTION

Danger of jamming on the lid!

3. Carefully close the lid.

Tighten the screw.

Tips and recommendations



This symbol highlights useful tips and recommendations as well as information for efficient and trouble-free operation.

Other markings

The following labels are used in this manual to highlight instructions, results, listings, references and other elements:

Labelling	Explanation
⇒	Step-by-step action instructions
↪	References to sections of this manual and to applicable documents
▪	Listings without a fixed order

2.2 Intended Use

The PureHum 1000 Pro evaporative humidifier is intended exclusively for humidifying room air in private and professional environments. Not intended for use in medical facilities!

Intended use also includes compliance with all the information in these instructions. Any use beyond the intended use or any other use is considered misuse.

WARNING

Danger in case of misuse!

- Misuse of the evaporative humidifier PureHum 1000 Pro can lead to dangerous situations.
- Operate humidifier only with fresh, cold ordinary tap water (max. 150 CFU/ml).
- Only use additives approved by Condair Ltd..
- Never operate the unit in humidifier mode with an empty water tank.
- Never operate the appliance near open water sources.
- Only operate the unit on a stable and horizontal surface.
- Never expose the appliance to strong heat sources.
- Never cover the appliance.
- Never place objects on the humidifier. This applies in particular to electrical appliances or containers filled with liquid.
- Never place the appliance near furnishings that absorb water (e.g. curtains, wallpaper or carpets).
- Never operate the unit in an explosive environment.

WARNING

Hygienic operation

- When operated with clean fresh drinking water and according to this manual, the unit is safe to use for humidification. However, drinking water contains bacteria and microorganisms. To ensure hygienic and proper operation of the humidifier, regular water replacement and cleaning is essential. If this is not observed, it may cause health problems under certain circumstances. Therefore, always follow the cleaning instructions and keep your appliance clean and fresh.

2.3 Symbols on the device

The following symbols and information signs are attached to the unit. They refer to the immediate environment in which they are applied.

WARNING

Danger if signage is illegible!

Over time, stickers and signs can become dirty or otherwise unrecognizable, so that hazards cannot be recognized and necessary operating instructions cannot be followed.


This creates a risk of injury.

- Keep all safety, warning and operating instructions in a legible condition at all times.
- Replace damaged signs or stickers immediately.



Sign "electrical voltage"

Warning of dangerous electrical voltage.



Pull out mains plug" sign

Always unplug the appliance from the mains before cleaning or troubleshooting.



Fill here" sign

This plate marks the filling opening of the water tank. Only use this opening for filling the water tank.

2.4 Safety and Dangers

The humidifier is designed according to the state of the art and current safety requirements. Nevertheless, there are residual dangers that require prudent action. The residual dangers and the resulting behaviour and measures are listed below.

Electric current

DANGER

Danger to life due to electric current!

In case of contact with live parts, there is an immediate danger to life due to electric shock. Damage to the insulation or individual components can be life-threatening.

- Only allow work on the electronics to be carried out by qualified electricians.
- If the mains cable is damaged, switch off the humidifier immediately and arrange for repair.
- Damaged mains connection cables may only be replaced by the manufacturer or its customer service or a similarly qualified person.
- Keep moisture away from live parts. This can lead to a short circuit.
- Never immerse the unit in water.
- Never point the outlet at electrical appliances or sockets.
- Always lay the mains cable so that it cannot come into contact with sources of heat, moisture, oil, sharp objects, sharp edges, etc.
- Always disconnect the mains plug before cleaning and troubleshooting.
- Never touch the mains plug with wet hands.
- When pulling the mains plug, always pull on the plug, never on the cable.
- Never pull the unit by the cable.

Children

WARNING

Risk of injury for children!

Children cannot assess the dangers when handling the humidifier. This can lead to serious injuries.


- Batteries and other small parts can be swallowed. Insert batteries immediately after receiving the humidifier or keep them out of reach of children.
- Packaging materials must not be used for play. There is an acute risk of suffocation. Dispose of packaging materials immediately or keep them out of reach of children.
- Always supervise children to ensure that they do not play with the appliance or use it as a climbing aid.

Inadequate cleaning

WARNING

Health hazard due to inadequate cleaning!

Poor cleaning can release bacteria and germs.

- Replace the evaporation filter after four months at the latest. If the ambient air is heavily contaminated, shorten the time interval accordingly.
- Always follow the cleaning intervals described in  „6.2 Cleaning schedule“ on page 28.
- Empty the water tank completely at least once a week and refill the water tank.

Humidity too high

WARNING

Health hazard due to excessive humidity!

Air that is too humid promotes the formation of mold and harmful germs.

- In living rooms, do not exceed the recommended value of 50 - 60 % humidity.
- To prevent damage to health, persons with asthma, respiratory diseases or lung complaints should consult a doctor before using the humidifier.
- In case of respiratory problems possibly related to the use of the humidifier, stop using the humidifier immediately and consult a doctor.

Proposition 65

WARNING

CALIFORNIA Proposition 65

This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Puddles of water

CAUTION

Risk of injury from slipping in puddles of water!

Slipping in puddles of water in the floor area can lead to a fall. This can lead to injuries.

- Place the humidifier on a horizontal surface.
- Wipe up puddles of water immediately with a cloth.
- Regularly check the safety drip tray (optional accessory) and empty it if necessary.

Stumble

⚠ CAUTION

Risk of injury from tripping over the mains cable!

Careless laying of the mains cable can cause tripping hazards. These can lead to falls and injuries.

- Lay the mains cable in such a way that there are no trip hazards.

Wrong choice of location

NOTICE

Risk of material damage due to incorrect placement of the humidifier!

If the humidifier is operated on floors that are not moisture-resistant, there is a risk of damaging them.

- Only place the humidifier on moisture-resistant floors.
- A safety drip tray to protect against leaking water (↪ „8.4 Safety drip tray" on page 52).
- Never place the appliance near furnishings that absorb water (e.g. curtains, wallpaper or carpets).

2.5 Responsibility of the operator

Operator

The operator is the person who operates the humidifier for commercial or economic purposes himself or who makes it available to a third party for use/application and who bears the legal product responsibility for the protection of the user, the personnel or third parties during operation. If the humidifier is used for commercial or economic purposes, the following operator obligations must be observed.

Operator duties

If the unit is used in the commercial sector, the operator is subject to the legal obligations for occupational safety.

In addition to the safety instructions in this manual, the safety, occupational health and safety and environmental protection regulations applicable to the area of use of the humidifier must be observed.

The following applies in particular:

- The operator must clearly regulate and define the responsibilities for installation, operation, troubleshooting and cleaning.
- The operator must ensure that all persons handling the unit have read and understood these instructions.
- The operator must provide the personnel with the required protective equipment and issue binding instructions for the wearing of the required protective equipment.
- The operator must ensure that the cleaning intervals described in these instructions are observed.

2.6 Personnel requirements

⚠ WARNING

Risk of injury if staff are not sufficiently qualified!

If unqualified persons carry out work on the humidifier, hazards arise which can cause serious injuries and considerable damage to property.

- All activities must only be carried out by qualified persons.
- Always keep unauthorized persons, especially children, away from the appliance.

This guidance identifies the staff qualifications listed below for the different areas of activity:

Operator

The operator uses and operates the unit within the scope of its intended use.

If the humidifier is used in a commercial or industrial environment, the operator must be instructed by the owner about the tasks assigned to him and possible dangers in case of improper behavior. The operator may only perform tasks that go beyond operation during normal operation if this is specified in these instructions and the operator has expressly entrusted him with them.

Manufacturer

Certain work may only be carried out by specialist personnel of the manufacturer. Other personnel are not authorized to carry out this work. Contact our customer service department to carry out any work that may be required.

Licensed electrician

Due to his many years of knowledge and experience as well as his knowledge of the relevant standards and regulations, the licensed electrician is able to carry out work on electrical systems and to independently recognize and avoid possible dangers. In addition, he must provide proof of his professional qualification, which certifies his ability to carry out work on electrical systems.

The licensed electrician must comply with the provisions of the applicable statutory accident prevention regulations.

Sanitation specialist

The sanitation specialist is trained and certified for the specific task area in which he/she works and knows the applicable standards and regulations.

Due to their professional training and experience, sanitary specialists are able to carry out work on all sanitary installations and to independently recognize and avoid possible hazards.

It must also provide evidence of its professional qualifications, certifying its ability to carry out work on sanitary installations.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children must not play with the appliance. Cleaning and user maintenance must not be carried out by children without supervision.

2.7 Environmental protection

NOTICE

Danger to the environment due to incorrect handling of environmentally hazardous substances!

Incorrect handling of environmentally hazardous substances, especially incorrect disposal, can cause considerable damage to the environment.

- Always observe the instructions below on handling and disposing of environmentally hazardous substances.
- If environmentally hazardous substances are accidentally released into the environment, take appropriate measures immediately. In case of doubt, inform the responsible local authority about the damage and ask for suitable measures

The following environmentally hazardous substances are used:

Batteries

Batteries contain toxic heavy metals. They are subject to hazardous waste treatment and must be handed in at municipal collection points or disposed of by a specialist

3. Transport and Storage

3.1 Safety instructions for transport and storage

Improper transport

NOTICE

Material damage due to improper transport!

In case of improper transport, transport pieces can fall or topple over. This can cause considerable damage to property.

- When unloading the transport pieces on delivery, proceed carefully and observe the symbols and instructions on the packaging.
- Always transport parcels upright and never throw them.
- Do not remove the packaging until shortly before commissioning.
- Never transport the humidifier when it is full. Water may leak out and cause damage to the unit or to furnishings.

3.2 Symbols on the packaging

The following symbols are affixed to the transport packaging:



Fragile

Marks packages with fragile or sensitive contents. Handle the package with care, do not drop it and do not subject it to shocks.



Protect from moisture

Protect packages from moisture and keep them dry.



Top

The arrowheads of the mark indicate the top of the package. They must always point upwards, otherwise the contents could be damaged.

3.3 Storage of the packages

Store packages under the following conditions:

- Do not store outdoors.
- Store in a dry and dust-free place.
- Do not expose to aggressive media.
- Protect from sunlight.
- Avoid mechanical shocks.
- Storage temperature: 5 to 40 °C (41 to 104 °F).
- Relative humidity: max. 55 %.
- If stored for longer than 3 months, regularly check the general condition of all parts and the packaging.



Under certain circumstances, there may be instructions for storage on the packages that go beyond the requirements mentioned here. Observe these accordingly.

3.4 Transport inspection

Check the delivery for completeness and transport damage immediately upon receipt.

In case of externally visible transport damage, proceed as follows:

- not accept delivery or accept it only with reservations.
- Note the extent of damage on the transport documents or on the carrier's delivery note.
- Initiate a complaint.



Complain about any defect as soon as it is detected. Claims for damages can only be asserted within the applicable complaint periods.

3.5 Storage when not in use

If the humidifier is taken out of operation for a longer period of time, proceed as follows:

Personnel:

▪ Operator

- ⇒ 1. Empty and clean the water tank (☞ „6.3.3 Cleaning the water tank" on page 34).
- ⇒ 2. Remove the evaporation filter (☞ „6.3.2.1 Changing the evaporation filter" on page 30).
- ⇒ 3. Clean the humidifier (☞ „6.3.4 Descale the unit" on page 35).
- ⇒ 4. Store the humidifier according to the instructions (☞ „3.3 Storage of packages" on page 13).

3.6 Transport humidifier

The humidifier has 4 castors on the underside. This allows the unit to be moved by pulling or pushing it. Observe the following points when moving the humidifier:

- Whenever possible, move the humidifier along the longitudinal axis. To do this, grasp the humidifier at the point marked in blue.



Fig. 3.6.1: Move humidifier

NOTICE

Danger of material damage due to tipping of the humidifier!

If the humidifier is pushed backwards and forwards, there is a risk that the unit will tip over. This can cause damage to the unit or the floor.

- Move the humidifier along the longitudinal axis whenever possible.
- Always empty the water tank before changing location.

- If the humidifier is pushed backwards and forwards, grip the underside additionally.




Fig. 3.6.2: Moving the humidifier forwards and

4. Commissioning

4.1 Safety instructions for initial commissioning

⚠ DANGER

Danger to life due to commissioning of a defective unit!

Starting up a defective unit can lead to life-threatening situations and cause considerable damage to property.

- Never operate a defective unit.
- Always check the mains cable for damage.

4.2 Requirements for the site

In order for the humidifier to function properly, observe the following points when selecting a location:

- Place the humidifier on a flat, horizontal surface.
- Ensure that the circulation of the air is guaranteed. The air inlet opening and air outlet opening must not be covered.
- Do not place the humidifier in traffic routes or in the swing area of doors.
- The distance to other objects in the environment must be at least 10 cm (4 inches) to the side and at least 10 cm (4 inches) above.
- For optimal function, the unit can be placed near a heat source. However, direct temperature exposure should not exceed 70 °C (158 °F).

Additional safety measures must be taken for water-sensitive floors.

4.3 Putting the humidifier into operation for the first time

To put the humidifier into operation, proceed as follows:

Preparation



Fig. 4.3.1: Removing the upper part of the housing

Staff:

▪ Operator

- ⇒ 1. Lift the upper part of the humidifier housing upwards and put it aside.
- ⇒ 2. Visually inspect the unit for defects and correct seating of the filter.



NOTICE

Make sure that the filter is positioned along the entire length of the water distribution inside the U-shaped rail. If individual fibers of the filter stick out, water could leak out of the appliance.




Fig. 4.3.2: Removing the cable outlet

- ⇒ Remove the side cover.
- ⇒ Remove the radio transmitter and cleaning brush from the unit.
- ⇒ Open the cable gland (1) and pass the mains cable through the opening.
- ⇒ Close the side panel again.
- ⇒ Replace the upper part of the housing.

NOTICE

There is a small notch in the cover of the cable guide. This is where the mains cable is inserted.



Putting the radio humidity transmitter into operation



Fig. 4.3.3: Opening the cover

Staff: ▪ Operator

- ⇒ 1. Carefully lift the cover of the radio humidity transmitter with a small screwdriver and remove it.




Fig. 4.3.4: Insert batteries

- ⇒ 2. Insert the appropriate batteries as shown in the illustration (1). The plus and minus poles are marked on both the circuit board and the batteries. The batteries are inserted correctly if these markings match.



The batteries required for the radio humidity transmitter are not part of the scope of delivery! Two AA batteries are required.




Fig. 4.3.5: Check functionality

- ⇒ 3. Check the radio humidity transmitter for proper functioning. To do this, press the black button (1).
 - ➔ The diode (2) lights up briefly, the radio humidity transmitter is ready for operation. If a warning tone sounds, the batteries must be replaced.

NOTICE


The radio humidity transmitter is delivered pre-coded from the factory. If you want a different coding, you can change it at any time (↪ chapter "5.6 Coding the radio humidity transmitter" on page 22).

Putting the humidifier into operation



Fig. 4.3.6: Switching on the humidifier

Staff: ▪ Operator

- ⇒ 1. Connect the mains plug of the humidifier to the mains.
- ⇒ 2. Switch the humidifier on via  on the touch display.
- ⇒ 3. Fill the water tank of the humidifier with tap water.
- ⇒ Proceed according to the instructions (☞ „5.3 Filling the water tank” on page 20).
- ⇒ 4. Enter the desired value for the air humidity via the "AIR HUMIDITY" menu item.
- ⇒ 5. Then adjust the fan speed using the fan menu*.

*Open the fan menu:





1. Select the "Fan speed" button  in the start menu
2. Open the main menu  and select the menu item "FAN" on page 2 



Fig. 4.3.7: PureHum 1000 Pro Start menu

NOTICE

The entry of new values (fan speed, target humidity, etc.) must always be confirmed with 

5. Operating the humidifier



This chapter only describes the operation of the standard version of the humidifier. For the operation of accessories, see chapter ↪ "8. Accessories" on page 45.

5.1 Displays on the device

Display of the fan speed




Abb. 5.1.1: Fan speed display

The speed of the fan can be adjusted in eight steps. In addition, the unit has an automatic function. The fan speed is shown on the touch display. With the automatic function, the unit regulates the fan power automatically, depending on the required power. This means that the change in humidity is measured via the radio humidity transmitter and the fan power is increased or reduced accordingly.

↪ For more information, see chapter "5.5 Setting the fan speed" on page 21.

Water level display




Fig. 5.1.2: Water level display

The water level is measured by a water level sensor in the water tank and shown on the touch display.

When the water supply has been used up and the lower level indicator is reached, the appliance switches off automatically. Due to its function, approx. 10 liters (2.5 gallons) of residual water remain in the appliance.

The message "WATER TANK EMPTY" appears on the display.

Display setpoint/actual value humidity




Fig. 5.1.3: Display setpoint & actual air

The setpoint value (1) corresponds to your preset humidity. This can be read in the center field of your touch display.

The current actual value (2) is displayed directly below.

Display current room temperature






Fig. 5.1.4: Display room temperature

The unit has a display of the current room temperature.

Display water change



Fig. 5.1.5: Display next recommended water change

The unit has a water change interval display. The interval can be individually adjusted to the conditions on site in the main menu  under the menu item "SERVICE" . The units are delivered from the factory with a preset water change interval of seven days.



NOTICE

The "CHANGE WATER" and "CLEAN UNIT" display always appear alternately for about 7 seconds.

Device cleaning display




Fig. 5.1.6: Next recommended cleaning display

The unit has a display of the cleaning interval. The interval can be set individually to the conditions on site in the main menu  under the menu item "SERVICE" . The units are delivered from the factory with a preset cleaning interval of 98 days.

Filter change indicator



Fig. 5.1.7: Display next recommended filter change

The unit has a filter change indicator that shows when a filter change is necessary depending on the running time of the pump, the water hardness and the fan. In the best case, the filter needs to be changed after 98 days, in the worst case after 56 days. This is only a recommendation, which can be influenced positively or negatively by external influences (air pollution). Despite this indication, the evaporation and cleaning filters must be checked visually for signs of wear. To change the filter, see chapter  "6.3.2.1 Changing the evaporative filter" on page 29.

Display notes and error messages



Fig. 5.1.8: Display notes & error messages

In the lower area of the touch display you will find a white field. Possible warning messages or notes are displayed here.
For an overview of the various messages, see chapter ↪ "7.2 Fault indication" on page 38.

5.2 Switching on and off

Switching on




Fig. 5.2.1: Switching on the unit



The radio humidity transmitter only sends a signal every three minutes. Therefore, the error code "Radio signal missing" always appears when switching on. However, this disappears automatically after three minutes at the latest. The process can be accelerated by breathing on the ventilation slots of the radio humidity transmitter.

Staff: ▪ Operator


- ⇒ 1. Make sure that the humidifier is properly connected to the mains.
- ⇒ 2. Fold the glass cover upwards.
- ⇒ 3. Press the [ON/OFF] button  on the touch display.
 - ➔ The humidifier is switched on.

Switch off



Fig. 5.2.2: Switching off the unit

Staff: ▪ Operator

- ⇒ 1. Press the [ON/OFF] button  on the touch display (bottom left corner). A small selection menu opens.
- ⇒ 2. Select "POWER OFF" to switch the unit to standby mode.

DANGER

Danger to life due to electric current!

The humidifier is not switched off, but is in standby mode. The unit is always supplied with power.

- Always unplug the appliance from the mains before cleaning or troubleshooting.

5.3 Filling the water tank

Improper filling

⚠ DANGER

Danger of electric shock if filled im- properly!
Improper filling can result in serious or fatal injury from electric shock.

- Carefully pour in the water.



Filling the water tank is not necessary for appliances with automatic water supply ↗ Chapter "8.2 Automatic water supply" on page 49.

NOTICE

Risk of material damage if filled incorrectly!

Incorrect filling of the water tank can lead to faults in the water level indicator or to defects in the appliance. In addition, water may leak from the appliance and cause damage to property.

- Fill the water tank only with fresh, cold, ordinary tap water (max. 150 KBE/ml, 150 CFU/ml). Fill the water tank on a liquid-resistant surface.
- Do not use flavorings.
- Make sure that no water is spilled and enters the unit.
- Completely empty and refill the water tank at least once a week.



Fig. 5.3.1: Opening the filler flap

Staff: ▪ Operator

- ⇒ 1. Connect the mains plug of the humidifier to the mains supply and switch on the humidifier.
- ⇒ 2. Fold the glass cover upwards (1).
- ⇒ 3. Use a watering can to carefully fill the water tank (maximum 50 liters / 13.2 gallons).
- ⇒ 4. Close the glass lid again.



→ The water level display shows the current fill level (max. 5 bars).

5.4 Set the desired humidity



Abb. 5.4.1: Air humidity display

Staff: ▪ Operator




- ⇒ 1. Select the menu item "AIR HUMIDITY".
- ⇒ 2. Set the desired target humidity value with the buttons  and .
- ⇒ 3. Confirm your entry with .



Fig. 5.4.2: Set target humidity

⚠ WARNING

Danger to health if the air is over humidified!

Over humidification of the air promotes the formation of germs and mould.

- It is recommended not to exceed 50 - 60 % humidity in living rooms.



The maximum adjustable humidity value is 90 %.

5.5 Setting the blower level






Fig. 5.5.1: Blower level display




Fig. 5.5.2: Setting the fan speed

Staff: ▪ Operator

- ⇒ 1. Open the settings menu.
- ⇒ 2. The fan speed is controlled via the buttons  and . The speed of the fan can be adjusted in eight steps. In addition, the unit has an automatic function.
- ⇒ 3. Confirm your entry with .



- ⇒ You can use the "MANUAL SETTING" button to switch back to manual mode and control the fan speed individually again.
- ⇒ Confirm your entry with .



5.6 Radio humidity transmitter

The humidifier and the radio humidity transmitter are matched to each other via a code. The units are delivered from the factory already coded. However, when using two or more units that are in close proximity to each other (0-20 meters, 0-65 feet), different coding may be necessary. If several units are operated in one room, the following possibilities exist:

- Several units are operated with one sensor. For this purpose, all units must have the same coding.
- Each unit is controlled via a separate sensor. For this purpose, all units must be coded differently.



Fig. 5.6.1: Interior view of radio humidity transmitter

⚠ DANGER

Danger to life due to electric current!
There is an immediate danger to life from electric shock if live parts are touched.

- Pull out the mains plug before opening the appliance.




Fig. 5.6.2: Slider for coding

The sliders for the coding are located on the respective circuit boards of the units. For each slider there is only the position "ON = up" and "OFF = down". Accordingly, there are 256 different coding variants.

i The coding of the humidifier and the corresponding radio humidity transmitter must match exactly. Otherwise the function is not guaranteed.

Encode radio humidity transmitter



Fig. 5.6.3: Opening the cover

Staff: ▪ Operator

- ⇒ 1. Carefully lift the cover of the radio humidity transmitter with a small screwdriver and remove it.

NOTICE

The electronics of the radio humidity transmitter are very sensitive. Take care not to touch the electronics or damage any components.

- ⇒ 2. code the radio humidity transmitter by adjusting the sliders (1) with a suitable non-metallic object.

NOTICE

Material damage due to short circuit!
Only code the radio transmitter with a non-metallic object.

- ⇒ 3. Close the cover of the radio humidity transmitter



Fig. 5.6.4: Coding the radio humidity transmitter

Code humidifier




Fig. 5.6.5: Touch display

Staff: ▪ Operator






- ⇒ 1. open the menu .
- ⇒ 2. select the radio humidity transmitter menu item .
- ⇒ 3. set the coding of the radio humidity transmitter in the humidifier.
- ⇒ 4. confirm your entry with .
- ⇒ 5. Use the buttons  and  to return to the main menu.
- ⇒ 6. Check the function of the system: To do this, carefully breathe into the housing of the radio humidity transmitter. The actual value displayed on the control panel changes. The radio humidity transmitter is ready for operation.



Fig. 5.6.6: Menu item "RADIO TRANSMITTER"



Fig. 5.6.7: Coding radio humidity transmitter

5.7 Change menu settings


The unit offers the possibility of making various settings according to one's own wishes, deviating from the factory settings. The visual representation of the menu is done via the touch display.

To change the menu setting, proceed as follows:



Fig. 5.7.1: Menu on/off

Staff: ▪ Operator

- ⇒ 1. To access the system settings, press  in the lower left corner of the display.
- ⇒ 2. Then select "SYSTEM SETTINGS" in the list view. Enter your PIN (3006, factory pre-coded) to access the settings.




- ⇒ 3. Confirm your entry with 





Fig. 5.7.2: System settings

The following settings can be managed here:

- UV lamp OFF/ON
- AWS (Automatic water supply) OFF/ON
- Flushing OFF/ON
- WLAN OFF/ON

If the parameters are set to "OFF", they are greyed out in the main menu and can no longer be called up and configured until this is enabled again in the system settings.

The following table gives an overview of the menu structure.

Menu	Submenu	Description	Setting	Comment
Main menu 	Operating mode	Setting the operating mode	<ul style="list-style-type: none"> ▪ Humidifier / Air Purifier ▪ Fixed value / timer 	The PureHum 1000 Pro can be used both as a humidifier and as an air purifier. In addition to normal operation, the PureHum 1000 Pro can also be operated via an integrated timer.
	Timer	Configuration of one or more timers for optimum adaptation of the humidifier to the conditions on site	By weekday and time (Mon-Sun)	The PureHum 1000 Pro can be programmed by means of an integrated timer.
	Radio transmitter	Configuration of the radio transmitter	<ul style="list-style-type: none"> ▪ 8-pin mode / 4-pin mode ▪ Coding 	
	Filter change	Next recommended filter change (in days)	Reset to desired filter change interval (in days)	Interval individually adaptable to local conditions (0-98 days)
	Signal tone	Configuration of the individual signal tones	OFF / ON	<ul style="list-style-type: none"> ▪ Water empty ▪ UV lamp defective ▪ Water sensor ▪ EEZ > 50 L ▪ Radio signal missing ▪ Filling signal
	Flushing	<ul style="list-style-type: none"> ▪ Configuration of the automatic flushing interval (in days) ▪ Start manual flushing 	<ul style="list-style-type: none"> ▪ Automatic flushing: <ul style="list-style-type: none"> ▪ Rinse after X days ▪ Flushing time ▪ Manual flushing <ul style="list-style-type: none"> ▪ "Rinse now!" 	Only in combination with AWS (automatic water supply)
	Network	Connect to network	<ul style="list-style-type: none"> ▪ Network selection ▪ Management of existing networks 	
	Ext. operation	Operation via external circuit	OFF / ON	
	Fan	Setting the fan speed and switching between manual and automatic mode	<ul style="list-style-type: none"> ▪ Manual mode: <ul style="list-style-type: none"> ▪ Level 1-8 ▪ Off ▪ Automatic mode 	
	Language	Setting the menu language	<ul style="list-style-type: none"> ▪ German ▪ English ▪ Spanish ▪ French ▪ Russian ▪ Italian 	
Date & time	Setting the date and time		Formats: <ul style="list-style-type: none"> ▪ Time = HH:MM ▪ Date = DD:MM:YYYY 	
Service	Service interval display <ul style="list-style-type: none"> ▪ Next recommended water change (in days) ▪ Next recommended general cleaning (in days) 		The number of days of the service intervals can be individually adapted to the conditions on site.	
	Switch off	Unit is set to standby mode		
	System settings	<ul style="list-style-type: none"> ▪ UV lamp ▪ AWS (automatic water supply) ▪ Flushing ▪ WLAN 	OFF / ON	Access only with device PIN
	Lock touch display	Display lock, as protection against unauthorized access	Activation and deactivation of the display lock with the device PIN	Home panel with parameters can still be viewed

5.8 Operating modes

You have the option of operating the unit as a humidifier or air purifier. The units are delivered from the factory in humidifier mode. In air purifier mode, the unit is operated without water. The fan always runs, but the water pump is deactivated.

5.8.1 Air purifier mode






Fig. 5.8.1.1: "OPERATION MODE" menu item

NOTICE

Possible contamination of the unit and working environment during insertion of the activated carbon cleaning filter.

You have the option of operating the unit as a humidifier or air purifier. The units are delivered from the factory in humidifier mode.

Staff: ▪ Operator

- ⇒ 1. In the main menu  select the menu item "OPERATING MODE" .
- ⇒ 2. Select the operating mode "AIR CLEANER".
- ⇒ 3. Confirm your selection with .
- ⇒ 4. Remove the evaporation filter and replace it with the activated carbon cleaning filter (↪ chapter "6.3.2.3 Inserting the activated carbon cleaning filter" on page 32).
- ⇒ 5. Replace the cleaning filters with the cleaning filters intended for the humidifier (↪ chapter "6.3.2.2 Replacing the cleaning filters" on page 31).

In air purifier mode, the unit is operated without water. The fan is always running but the water pump is deactivated.

5.8.2 Humidifier mode






Fig. 5.8.2.1: "OPERATION MODE" menu item

NOTICE

Clean the appliance thoroughly after removing the activated carbon cleaning filter. Activated carbon particles can get into the water circuit, which can clog water-carrying components in the appliance. Possible consequences may be reduced evaporation capacity and water leakage.

In humidifier mode, the unit is operated with water again as usual. The water pump is now active again.

Staff: ▪ Operator

- ⇒ 1. in the main menu  select the menu item "OPERATING MODE" .
- ⇒ 2. Select the operating mode "AIR HUMIDIFIER".
- ⇒ 3. Confirm your entry with .
- ⇒ 4. Replace the activated carbon cleaning filter with the evaporative filter (↪ chapter "6.3.2.1 Replacing the evaporative filter" on page 30).
- ⇒ 5. Replace the cleaning filters with the cleaning filters intended for the air purifier mode (↪ chapter "6.3.2.2 Replacing the cleaning filters" on page 32).

5.8.3 Operating modes fixed value & timer



Fig. 5.8.3.1: "TIME SWITCH" menu item







Fig. 5.8.3.2: "TIME SWITCH" menu item

The PureHum 1000 Pro offers you the option of controlling the humidification over time. In the factory setting, the unit is set to the desired target humidity value in fixed value mode and thus maintains the humidity in the desired humidity range. Alternatively, you can programme your PureHum 1000 Pro with a timer. The unit then brings the humidity to the desired humidity at the desired time.

Staff: ▪ Operator

- ⇒ 1. in the main menu  select the menu item "TIME SWITCH" .
- ⇒ 2. Set the desired time and fan level.
- ⇒ 3. Confirm your entry with .

If you have selected the "TIME SWITCH" mode, you can configure the times under the menu item "TIME SWITCH" (☞ see the following note).

NOTICE

The B 600 humidifier works with switching times.

The timer setting works with switching times. When you set the desired level, the unit runs at the set level from the set time until the time when a new command is set. An end point must therefore be set.

Example: The unit runs in automatic mode, but should only run at level 1 in the time period from 2:00 p.m. to 4:00 p.m. because it should be as quiet as possible in the room. **Setting:** Switching point 0 = 2:00 p.m. level 1; switching point 1 = 4:00 p.m. level AUTO.

6. Clean humidifier and maintain

6.1 Safety instructions for cleaning and care

Improper cleaning

DANGER

Danger to life due to improper cleaning! Improper cleaning of the humidifier can lead to serious or even fatal injuries.

- Always disconnect the mains plug before cleaning.
- Wear protective gloves and goggles when working with limescale remover.

NOTICE

Risk of material damage due to improper cleaning! Improper cleaning of the humidifier can cause damage to the unit as well as to the floor and furnishings.

- Do not use aggressive cleaning agents such as benzene, scouring agents or agents containing chlorine, which attack plastics.
- Always clean on a surface that is not sensitive to water.
- Make sure that no electronic components come into contact with water.
- Make sure that the unit is dry before putting it back into operation.

Poor cleaning

WARNING

Health hazard due to inadequate cleaning!

Poor cleaning can release bacteria and germs.

- Replace the evaporation filter after four months at the latest. If the ambient air is heavily contaminated, shorten the time interval accordingly.
- Always adhere to the described intervals for cleaning (☞ chapter "6.2 Cleaning schedule" on page 28).
- Completely empty and refill the water tank at least once a week.

Protective equipment

Protective gloves and goggles must be worn when working with limescale remover.



Chemical-resistant protective gloves Chemical resistant protective gloves are used to protect the hands from skin-irritating substances.



Safety goggles The safety goggles are used to protect the eyes from splashes of liquid.

6.2 Cleaning schedule

	Interval *	Maintenance work	Staff
HUMIDIFIER MODE	daily	Check the water level. The appliance switches off automatically at a residual water level of approx. 15 litres (4 gallons) (not applicable with automatic water supply).	Operator
		Check the humidity value via the display on the control panel.	Operator
	weekly	Change the water and rinse the tank well.	Operator
	monthly	Clean the humidifier thoroughly (↪ chapter "6.3.1 Monthly cleaning" on page 28).	Operator
	every 3-4 months	Replace the evaporation filter (↪ chapter "6.3.2.1 Replacing the evaporation filter" on page 30).	Operator
		If necessary, remove limescale residues from the water tank (↪ chapter '6.3.3 Cleaning the water tank' on page 34).	Operator
annual	Perform basic cleaning of the appliance with limescale remover (↪ chapter "6.3.4 Descaling the appliance" on page 35).	Operator	
	Clean the UV disinfection and lime conversion cartridge (optional accessory) (↪ chapter "8.1.1 Cleaning the UV disinfection and lime conversion cartridge" on page 46).	Operator	
AIR PURIFIER MODE	daily	Check the humidity value via the touch display.	Operator
	monthly	Clean the unit thoroughly (↪ chapter "6.3.1 Monthly cleaning" on page 28).	Operator
	every 3-4 months	Replace the activated charcoal cleaning filter (↪ chapter "6.3.2.3 Inserting the activated charcoal cleaning filter" on page 33).	Operator

*The specified time intervals apply at normal water quality and normal dust accumulation in the air and may therefore vary.

6.3 Cleaning work

6.3.1 Monthly Cleaning

⚠ WARNING


Danger of electric shock if the mains plug is not pulled out!



Staff: ■ Operator

- ⇒ 1. Switch off the humidifier and unplug it from the mains. Turn off the water supply, if applicable.
- ⇒ 2. Lift the upper part of the humidifier housing upwards and place it to one side.
- ⇒ 3. Check the evaporation filter for dirt. Replace the evaporation filter if it is very dirty (↪ chapter "6.3.2.1 Replacing the evaporation filter" on page 30).

Fig. 6.3.1.1: Removing the upper part of the housing



- ⇒ 4. Check the drain holes in the water distribution (1) for blockages. Remove residues such as limescale or dust with a needle, screwdriver or wet vacuum cleaner.

Fig. 6.3.1.2: Cleaning drain holes



Fig. 6.3.1.3: Opening the side cover

- ⇒ 5. Open the side cover.
- ⇒ 6. Remove the cable grommet on the back of the unit and thread the power cable through the opening in the housing.
 - ➔ If necessary, disconnect the connections for the automatic water supply



Fig. 6.3.1.4: Lifting off the middle section

- ⇒ 7. Lift the center section out of the water tank and place it on the side surface.
- ⇒ 8. Empty the water tank.
- ⇒ 9. Clean the water tank with a sponge.




Fig. 6.3.1.5: Clean the water level sensor if necessary.

- ⇒ 10. Check the water level sensor (1) for dirt. If necessary, remove limescale and other residues with a cloth or sponge.
- ⇒ 11. Put the center part back into the water tank.



Fig. 6.3.1.6: Connection of power cable, if necessary, AWS & flushing device

- ⇒ 12. Thread the power cable back through the opening in the housing and reattach the cable grommet. If necessary, reconnect the automatic water supply and the automatic rinsing device.
- ⇒ 13. Close the side panel.
- ⇒ 14. Replace the upper part of the housing.
- ➔ The monthly cleaning is finished.

6.3.2 Change filter

6.3.2.1 Change evaporation

Remove old filter



Fig. 6.3.2.1: Removing the upper part of the housing



Fig. 6.3.2.2: Remove filter bracket




Fig. 6.3.2.3: Filter removed



Replacement evaporative filters can be ordered from your local specialist dealer.

Order number:

- 2139320: BIO filter PureHum 1000 Pro (pack of 2)
- 2139322: Foam filter PureHum 1000 Pro



WARNING

Risk of electric shock if the mains plug is not disconnected!

Staff: ▪ Operator

- ⇒ 1. Switch off the humidifier and disconnect the mains plug. Turn off the water supply, if applicable.
- ⇒ 2. Lift the upper part of the humidifier housing upwards and put it to one side.

- ⇒ 3. Press the filter bracket (1) together and unhook it.

- ⇒ 4. Unhook the filter from the fastening hooks (1). Then loosen and remove the filter along the water distribution.

Insert new filter




Fig. 6.3.2.4: Fixing the filter

- ⇒ 5. Insert the new filter and fix it along the water distribution.
- ⇒ 6. Fix the filter on both sides to the fastening hooks (1).



Fig. 6.3.2.5: Incorrect fit of the filter

- ⇒ 7. Check that the filter is firmly seated in the water distribution rail and that no fibers are protruding.



Make sure that the filter is positioned inside the U-shaped rail along the entire length of the water distribution. If this is not the case, water may leak out of the unit.



Fig. 6.3.2.6: Inserting the clamping bracket

- ⇒ 8. Replace the clamping bracket.






Ensure that the clamping brackets are correctly seated. The filter must not touch the housing as this may cause water to leak out.

- ⇒ 9. Replace the upper part of the humidifier housing.

Filter change indicator



Fig. 6.3.2.7: Reset filter change indicator

- ⇒ 10. open the main menu .
- ⇒ 11. open the menu item "CHANGE FILTER". .
- ⇒ 12. Reset the filter change indicator.
- ⇒ 13. Confirm your entry with .

6.3.2.2 Change cleaning filter

In addition to the evaporation filter or activated charcoal cleaning filter, the PureHum 1000 Pro humidifier has a coarse dust filter and a cleaning filter installed in each intake grille to remove coarse dirt from the intake air. We recommend a regular visual inspection.

Remove old filter



Fig. 6.3.2.2.1: Opening the intake grille



Fig. 6.3.2.2.2: Loosening the retainer




Fig. 6.3.2.2.3: Inserting the cleaning filter set



Fig. 6.3.2.2.4: Fastening the retaining rubbers



Replacement cleaning filters can be reordered from your local specialist dealer.
Order number (by operating mode):
Fine dust filter set F7 (humidifier): 2606966
Hepa filter set (air purifier): 2606968



WARNING

Danger of electric shock if the mains plug is

Staff: ■ Operator

- ⇒ 1. Switch off the humidifier and unplug it from the mains.
- ⇒ 2. Open the intake grille (filter support) by folding the component away from the unit. The intake grille is held by two magnets. There is no need to open any release.

NOTICE

Cleaning filters are installed on both sides of the PureHum 1000 Pro. Changing the opposite filters is also done as described here.

- ⇒ 3. Remove the retaining rubbers from the intake grille.
- ⇒ 4. Remove the cleaning filter and the coarse filter.

- ⇒ 5. Insert the coarse filter (1).
- ⇒ 6. Insert the cleaning filter (2).

- ⇒ 7. Insert the coarse filter (1).
- ⇒ 8. Insert the cleaning filter (2).

6.3.2.3 Insert activated charcoal cleaning filter

In air purifier operating mode, the evaporative filter is replaced by an activated carbon cleaning filter.

Remove old filter



Fig. 6.3.2.3.1: Remove evaporation filter



Fig. 6.3.2.3.2: PureHum 1000 Pro without filter




Fig. 6.3.2.3.3: PureHum 1000 Pro with activated carbon cleaning filter



Replacement evaporative filters can be ordered from your local dealer (order number: 2606967).



WARNING

Danger of electric shock if the mains plug is not pulled out!

Staff: ▪ Operator

- ⇒ 1. Switch off the humidifier and unplug it from the mains.
- ⇒ 2. Lift the upper part of the humidifier housing upwards and put it aside.
- ⇒ 3. Press the filter bracket together and unhook it.


- ⇒ 4. Unhook the filter from the fastening hooks. Then loosen and remove the filter along the water distribution.

NOTICE

Possible contamination of the unit and the work environment during insertion of the activated carbon cleaning filter.

We recommend placing the activated charcoal cleaning filter on a surface that can be cleaned easily. If the filter mat is bent, activated charcoal particles may crumble out.

- ⇒ 5. Insert the activated carbon cleaning filter and fix it along the water distribution.
- ⇒ 6. Fix the filter on both sides to the fastening hooks (1).
- ⇒ 7. Check that the filter is seated in the water distribution rail.
- ⇒ 8. Replace the clamping bracket (2) on both sides.
- ⇒ 9. Replace the upper part of the humidifier housing.



NOTICE

Thorough cleaning must be carried out when you switch from air purifier mode to humidifier mode. Clean the appliance thoroughly after removing the activated carbon cleaning filter. Activated charcoal particles can get into the water circuit and clog water bearing components in the appliance.

WARNING

Possible problems due to inadequate cleaning!

Particles of the activated carbon cleaning filter can get into water-bearing components due to inadequate cleaning. This can lead to reduced evaporation performance and water leakage. Activated carbon particles can be released into the air through the evaporation filter.

6.3.3 Cleaning the water



⚠ WARNING

Danger of electric shock if the mains plug is not pulled out!



Fig. 6.3.3.1: Removing the upper part of the housing




Fig. 6.3.3.2: Opening the side cover



Fig. 6.3.3.3: Lifting off the middle section



Fig. 6.3.4.4: Connection of power cable, AWS & flushing device

Staff:

Protective equipment:

Materials:

- Operator
- Chemical-resistant protective gloves
- Safety goggles
- Limescale remover

- ⇒ 1. Switch off the humidifier and disconnect the mains plug. Turn off the water supply, if applicable.
- ⇒ 2. Lift the upper part of the humidifier housing upwards and put it to one side.

- ⇒ 3. Open the side cover.
- ⇒ 4. Remove the cable grommet on the back of the unit and thread the power cable through the opening in the housing.
 - ➔ If necessary, disconnect the connections for the automatic water supply and flushing device.



- ⇒ 5. Lift the center section out of the water tank and place it on the side surface.
- ⇒ 6. Empty the water tank.
- ⇒ 7. Clean the water tank with limescale remover. Allow the limescale remover to act briefly. Follow the instructions on the packaging of the limescale remover.
- ⇒ 8. To avoid limescale remover residues, rinse the water tank thoroughly with tap water.

- ⇒ 9. Put the center part back into the water tank.
- ⇒ 10. Thread the power cable through the opening in the housing and attach the cable gland. If necessary, reconnect the automatic water supply and the automatic flushing device (for AWS unit with flushing device).
- ⇒ 11. Close the side panel.
- ⇒ 12. Replace the upper part of the housing.

6.3.4 Descaling the appliance

Preparation



⚠ WARNING

Risk of electric shock if the mains plug is not disconnected!

NOTICE

Risk of property damage due to the use of aggressive limescale removers!

Aggressive limescale removers can cause damage to the appliance and its surroundings, for example to floors.

- Only use suitable limescale removers.
- Before descaling, follow the instructions on the packaging of the limescale remover.
- Place the appliance on a suitable non-sensitive surface for descaling.



Fig. 6.3.4.1: Removing the upper part of the housing

Staff:

Protective equipment:

Materials:

- Operator
- Chemical-resistant protective gloves
- Safety glasses
- Limescale remover

- ⇒ 1. Switch off the humidifier and disconnect the mains plug. Turn off the water supply, if any.
- ⇒ 2. To prevent damage to the floor, place the humidifier on a moisture-resistant floor.
- ⇒ 3. Lift the upper part of the humidifier housing upwards and put it aside.
- ⇒ 4. Remove the evaporation filter (↪ chapter "6.3.2.1 Changing the evaporation filter" on page 30).
- ⇒ 5. To avoid damaging the blower, disconnect the blower connector by pressing the connector clips and pull it out. Cover the fan with a foil or remove the fan (↪ chapter "7.4.2 Replacing the fan" on page 43).
- ⇒ 6. Replace the upper part of the housing.
- ⇒ 7. Add limescale remover diluted with approx. 10 litres (3 gallons) of water to the water tank according to the information on the packaging.
- ⇒ 8. Put the humidifier back into operation and let it run in this state for approx. 12 hours.

Cleaning



Fig. 6.3.4.2: Removing the upper part of the housing



⚠ WARNING

Danger of electric shock if the mains plug is not pulled out!

Staff:

Protective equipment:

Materials:

- Operator
- Chemical-resistant protective gloves
- Safety goggles
- Limescale remover

- ⇒ 1. Switch off the humidifier and disconnect the mains plug. Turn off the water supply, if applicable.
- ⇒ 2. Lift the upper part of the humidifier housing upwards and put it to one side.
- ⇒ 3. Remove the cleaning brush from the side compartment.




Fig. 6.3.4.3: Opening the side cover

- ⇒ 4. Open the side cover.
- ⇒ 5. Remove the cable gland (1) on the back of the unit and thread the power cable through the opening in the housing.
 - ➔ If necessary, disconnect the connections for the automatic water supply (2) and flushing device (3).
- ⇒ 6. Lift the centre section out of the water tank and place it on the side surface.
- ⇒ 7. Place a suitable container under the pump hoses to collect any residual water.




Fig. 6.3.4.4: Pulling off the pump hoses

- ⇒ 8. Pull off the pump hoses (1).



Fig. 6.3.4.5: Cleaning the pump hoses

- ⇒ 9. Clean the pump hoses with the cleaning brush. Replace pump hoses if they are heavily soiled or worn (order number: 2139449).
- ⇒ 10. Reattach the pump hoses.



Make sure that the pump hoses are tight. Otherwise, there is a risk of water leaking out.



Fig. 6.3.4.6: Cleaning the pump body

- ⇒ 11. Clean the pump body (1) with a cloth.



Fig. 6.3.4.7: Opening the pump body



Dirt and limescale often also settle in the pump body around the pump blade, which means that the pump can no longer develop its full performance. We therefore recommend cleaning the inside of the pump body as well.

- ⇒ 12. Use a small slotted screwdriver to prize open the pump cover at the notch (1). Be careful not to damage any surrounding components.



Fig. 6.3.4.8: Pump body with open pump cover

- ⇒ 13. Clean the inside of the pump body with a damp cloth or the enclosed cleaning brush.



Fig. 6.3.4.9: Fitting the pump cover

- ⇒ 14. Once all impurities have been removed, the pump cover can be refitted. Press the pump cover onto the pump body. Make sure that the side with the flat surface is visible from the outside. If the pump cover is fitted incorrectly, the pump blade could block.




Fig. 6.3.4.10: Clean water level sensor

- ⇒ 15. Clean the water level sensor (1). Depending on the degree of contamination, use a sponge or fine-grained sandpaper.
- ⇒ 16. To avoid limescale remover residues in the appliance, rinse thoroughly with tap water.
- ⇒ 17. Put the center part back into the water tank.




Fig. 6.3.4.11 Blower PureHum 1000 Pro

⇒ 18. vacuum the surface of the fan (1) with a Hoover nozzle.



Fig. 6.3.4.12: Connection of power cable, AWS & flushing

- ⇒ 19. Thread the power cable back through the opening in the housing and reattach the cable grommet. If necessary, reconnect the automatic water supply and the automatic rinsing device.
- ⇒ 20. Close the side panel.
- ⇒ 21. Replace the upper part of the housing.

7. Recognize faults and rectify them

7.1 Safety instructions for Troubleshooting

⚠ DANGER

Danger to life due to improper troubleshooting!

Improper troubleshooting can result in serious injury or death.

- Always disconnect the mains plug before troubleshooting.
 - Only remedy the faults yourself that are described below.
- ➔ For all other problems, contact the manufacturer.

7.2 Fault indication

The PureHum 1000 Pro evaporative humidifier has an independent monitoring system that makes it possible to quickly and reliably detect faults and react accordingly.



Fig. 7.2.1: Fault display on the touch display

If there is a fault, it is indicated via the fault message display on the touch display. The fault display can be combined with an acoustic signal. This means that a beep also sounds. This setting can be selected independently by the user. See ↪ chapter "5.7 Changing menu settings" on page 24 (table).

Error display

The following table shows the problems that may occur and the corresponding solutions to the problem.

Error display	Remedy	Staff
Water tank empty.	<ul style="list-style-type: none"> ▪ Check the water level. Fill the water tank if necessary (↪ chapter '5.3 Filling the water tank' on page 21). ▪ If an automatic water supply is used, check that it is working properly. 	Operator
UV lamp defective (optional accessory).	<ul style="list-style-type: none"> ▪ Replace the UV lamp (↪ chapter "8.1.2 Replacing the UV lamp" on page 48). 	Operator
Water leakage detected (only possible with external water sensor [optional accessory]).	<ul style="list-style-type: none"> ▪ Check the correct fit of the filter. ▪ Check that the unit is standing on a level surface. ▪ If an automatic water supply is used, check it for leaks and functionality. ▪ Check the water tank for leaks. 	Operator
Water tank too full (only possible with automatic water supply [optional accessory]).	<ul style="list-style-type: none"> ▪ Check that the solenoid valve is functioning properly. ▪ Check water level sensor for dirt and clean if necessary (↪ chapter "6.3.1 Monthly cleaning" on page 28). 	Operator
Radio signal missing. The receiver on the touch display has not received a signal from the radio humidity transmitter for some time.	<ul style="list-style-type: none"> ▪ Check the functionality of the radio humidity transmitter. Replace the batteries if necessary (↪ chapter "5.6 Coding the radio humidity transmitter" on page 22). ▪ Check the coding of the radio humidity transmitter (↪ chapter "5.6 Radio humidity transmitter coding" on page 22). ▪ Reduce the distance between the radio humidity transmitter and the humidifier. Concrete and steel walls can impair reception. 	Operator
Refilling time	<ul style="list-style-type: none"> ▪ Safety shut-off of the solenoid valve; no water runs into the appliance. ▪ Switch off the humidifier and disconnect the mains plug. Then reconnect the mains plug and switch the appliance on again. 	Operator
Fan	<ul style="list-style-type: none"> ▪ Safety shutdown ▪ Switch off the humidifier and disconnect the mains plug. Then reconnect the mains plug and switch the appliance on again. 	Operator

7.3 Error table

If there is no error and the unit still does not work properly, check the following points:

Error description	Cause	Remedy	Staff
No function, humidifier does not start.	Unit not switched on.	Switch on the unit ↪ chapter "5.2 Switching on and off" on page 20.	Operator
	Unit not connected or not connected correctly.	Make sure that the mains plug of the humidifier is connected to the mains.	Operator
Empty water tank" error	Water level too low.	Refill water ↪ chapter "5.3 Filling the water tank" on page 21.	Operator
	Water level sensor dirty.	Clean the water level sensor ↪ chapter "6.3.4 Descale the appliance" on page 35.	Operator
The humidifier is switched on, but the fan does not start.	The humidity of the air is higher than the set target humidity.	If necessary, change the setpoint ↪ chapter "5.4 Setting the desired air humidity" on page 21.	Operator
	Fan defective.	Replace fan ↪ chapter "7.4.2 Replace fan" on page 43.	Operator
	Connector of the fan is defective.	Check plug connection and cable. Replace if necessary.	Licensed electrician
The unit is running, but there is no water in the water distribution system.	Pump hoses not properly attached or dirty.	Clean the pump hoses or fit them correctly ↪ chapter "6.3.4 Decalcifying the unit" on page 35.	Operator
	Lime conversion cartridge (optional accessory) clogged.	Clean the limescale conversion cartridge ↪ chapter "8.1.1 Cleaning the UV extraction and limescale conversion cartridge" on page 46.	Operator
	Pump defective.	Replace pump ↪ chapter "7.4.1 Replace pump" on page 41.	Operator
Water gutter overflows.	Drain holes are blocked.	Clean the water distribution and drain holes ↪ chapter "6.3.1 Monthly cleaning" on page 28.	Operator
Water leaks from the appliance.	Water tank leaks.	Check the water tank for damage.	Operator
	The unit is crooked.	Check location and adjust if necessary ↪ chapter "4.2 Requirements for the location" on page 15.	Operator
	Filter is used up.	Replace the filter ↪ chapter "6.3.2.1 Replacing the evaporation filter" on page 30.	Operator
	Filter not inserted correctly.	Check the fit of the filter. Make sure that the filter does not touch the housing and that no fibers are sticking out.	Operator
	Pump hoses not properly attached or dirty.	Fit the pump hoses correctly, clean if necessary ↪ chapter "6.3.4 Descaling the appliance" on page 35.	Operator
Automatic water supply (optional accessory) does not fill up with water.	Automatic water supply (optional accessory) defective.	Have the automatic water supply repaired by a plumbing specialist or by the manufacturer's specialist personnel.	Sanitary specialist / manufacturer
Automatic water supply (optional supply) runs continuously.	Solenoid valve does not close.	Check the water level sensor for dirt and clean if necessary ↪ chapter "6.3.1 Monthly cleaning" on page 28.	Operator
	Solenoid valve defective.	Have the solenoid valve replaced. To do this, contact the local trade partner.	Licensed electrician
Water monitor (optional accessory) gives an acoustic signal.	Water has leaked out.	Find and eliminate the cause, clean the tank. Then disconnect the water monitor from the mains for a few seconds.	Operator
Radio humidity transmitter gives acoustic signal.	Batteries in the radio humidity transmitter empty.	Replace batteries.	Operator
Automatic flushing device is running.	Drain positioned too low	Set the drain higher ↪ "8.3 Automatic flushing system" on page 51.	Operator
Newly inserted batteries do not work.	Batteries were inserted incorrectly - polarity not observed.	Insert the batteries correctly ↪ chapter "4.3 Putting the humidifier into operation for the first time" on page 15.	Operator
Fan error display	Fan blocked	Switch off the humidifier and unplug it from the mains. Check the fan for objects that could block the fan wheel.	Operator

7.4 Correct error

7.4.1 Replace pump

Remove old pump



Fig. 7.4.1.1: Removing the upper part of the housing




Fig. 7.4.1.2: Opening the side cover



Fig. 7.4.1.3: Remove centre part



Fig. 7.4.1.4: Putting down the centre part sideways



A new pump can be ordered from your local dealer (order no. 2139443).



⚠ WARNING

Danger of electric shock if the mains plug is not pulled out!

Staff: ▪ Operator

- ⇒ 1. Switch off the humidifier and disconnect the mains plug. Turn off the water supply, if any.
- ⇒ 2. Lift the upper part of the humidifier housing upwards and put it to one side.
- ⇒ 3. Open the side cover.
- ⇒ 4. Remove the cable gland (1) on the back of the unit and thread the power cable through the opening in the housing.
 - ➔ If necessary, disconnect the connections for the automatic water supply (2) and flushing device (3).
- ⇒ 5. Lift the center section out of the water tank.
- ⇒ 6. put the middle part to the side.
- ⇒ 7. Place a suitable container under the pump hoses to collect any residual water.





Fig. 7.4.1.5: Pulling off the pump hoses

⇒ 8. Pull off the pump hoses.



Fig. 7.4.1.6: Loosening the water pump

⇒ 9. loosen the water pump in the direction of the arrow to the right and pull it out carefully.



Fig. 7.4.1.7: Loosening the plug connection

⇒ 10. Disconnect the connector (1) in the cable shaft under the touch display.

Insert new pump



Fig. 7.4.1.8: Attach the pump

- ⇒ 11. Connect the plug connection of the new pump.
- ⇒ 12. Insert the water pump into the opening and turn it to the left in the direction of the arrow until it engages and is firmly seated.
- ⇒ 13. Take care not to crush the pump cable when inserting it.



Fig. 7.4.1.9: Attach pump hoses

- ⇒ 14. Reattach the pump hoses.



Make sure that the pump hoses are tight. Otherwise, there is a risk of water leaking out.



Fig. 7.4.1.10: Connection of power cable, if necessary AWS &

- ⇒ 15. Place the centre section in the water tank.
- ⇒ 16. Thread the power cable through the opening in the housing and attach the cable grommet. If necessary, connect the automatic water supply and the automatic flushing device.
- ⇒ 17. Close the side panel.
- ⇒ 18. Put on the upper part of the housing.

7.4.2 Replace blower

Remove old blower



A new blower can be ordered from your local dealer (order number: 2606987).



Fig. 7.4.2.1: Removing the upper part of the housing



⚠ WARNING

Danger of electric shock if the mains plug is not pulled out!

Staff: ▪ Operator

- ⇒ 1. Switch off the humidifier and unplug it from the mains.
- ⇒ 2. Lift the upper part of the humidifier housing upwards and put it on one side.
 - ➔ The fan is located in the center section next to the touch display.




Fig. 7.4.2.2: Opening the side cover

- ⇒ 3. Open the side cover.
- ⇒ 4. Remove the cable grommet on the back of the unit and thread the power cable through the opening in the housing.
 - ➔ If necessary, disconnect the connections for the automatic water supply and flushing device.





Fig. 7.4.2.3: Remove center part

⇒ 5. Lift the center section out of the water tank and place it to the side.




Fig. 7.4.2.4: Loosening the fan plug

⇒ 6. Loosen the fan plug by pressing the plug clips and pull it out (1).




Fig. 7.4.2.5: Loosening the screw

⇒ 7. Loosen the three screw connections on the underside counterclockwise and unscrew them completely (1).

NOTICE

Make sure that the fan does not fall out after loosening the screws.

⇒ 8. Remove the fan.

Insert new blower



Fig. 7.4.2.6: Connecting the fan plug

- ⇒ 9. Insert a new blower.
- ⇒ 10. Insert the screw threads on the vibration dampers through the holes in the center plate.
- ⇒ 11. Screw the fan to the underside of the center section.
- ⇒ 12. Connect the fan plug (1).
- ⇒ 13. Place the center section in the water tank.



Fig. 7.4.2.7: Connection of power cable, AWS & flushing device

- ⇒ 14. Thread the power cable through the opening in the housing and reattach the cable grommet. If necessary, connect the automatic water supply and the automatic flushing device.
- ⇒ 15. Close the side panel.
- ⇒ 16. Put on the upper part of the housing.

8. Accessories

The accessories that can be ordered in addition to the standard version of the humidifier are described below. Some accessories may only be installed by the manufacturer. In this case, contact the manufacturer.

⚠ WARNING

Risk of injury due to the use of incorrect accessories!

The use of incorrect or faulty accessories can be dangerous for the user and cause damage, malfunctions or total failure.

- Only use original accessories from Condair Ltd. or accessories approved by the manufacturer.
- If you are unsure, always contact our service department.

8.1 UV disinfection and lime conversion cartridge

⚠ WARNING

Health hazard due to toxic mercury vapor!

The tube of the UV lamp contains toxic mercury. If the mercury vapors are inhaled, there is an acute danger of poisoning.

- When changing the UV lamp, always proceed carefully and do not damage the UV lamp.
- Never dispose of the UV lamp in household waste. Contact your local authority or specialist waste disposal company for information on environmentally friendly disposal.



Order numbers:

- UV lamp: 2606969
- Lime conversion cartridge: 2139457



Prerequisite:

The installation of the UV disinfection system is carried out exclusively by the manufacturer.

Description

Irradiating the water with UV light kills germs and microorganisms in the water. The humidifier water is disinfected and returns to the water circuit of the unit with a reduced germ count.

In addition, the appliance is equipped with a lime conversion cartridge, which changes the molecular structure of the lime in such a way that it can no longer be deposited on surfaces in the appliance.

8.1.1 UV disinfection and lime conversion cartridge cleaning

UV disinfection clean



Fig. 8.1.1.1: Removing the upper part of the housing




Fig. 8.1.1.2: Opening the side cover



Fig. 8.1.1.3: Remove center part



Fig. 8.1.1.4: UV disinfection




WARNING

Danger of electric shock if the mains plug is not pulled out!

- Staff:
- Operator
- Protective equipment:
- Chemical-resistant protective gloves
 - Safety goggles
- Materials:
- Limescale remover
- ⇒ Switch off the humidifier and unplug it from the mains.
- ⇒ Lift the upper part of the humidifier housing upwards and put it to one side.

- ⇒ 3. Open the side cover.
- ⇒ 4. Remove the cable gland (1) on the back of the unit and thread the power cable through the opening in the housing.
- If necessary, disconnect the connections for the automatic water supply (2) and flushing device (3).




- ⇒ 5. Remove the side panel and remove/disconnect the power cable and, if necessary, the connections for the automatic water supply.
- ⇒ 6. Lift the center section out of the water tank.

- The UV disinfection unit is located below the center plate next to the pump (1).
- ⇒ 7. Check the stainless-steel pipe for damage and contamination. If necessary, remove contamination with a cloth and lime remover.



Fig. 8.1.1.5: Cleaning the pump hoses

- ⇒ 8. Pull the pump hoses off the stainless-steel pipe and clean them with the cleaning brush. Replace the pump hoses if they are very dirty or worn.



- ⇒ 9. Clean the plastic Y-piece (1) carefully with the cleaning brush.

⚠ WARNING

If the UV lamp inside the stainless-steel tube is damaged, toxic

- ⇒ 11. Reattach the pump hoses to the stainless-steel pipe.



Prerequisite:

Make sure that the pump hoses are tight. Otherwise, there is a risk of water leaking out.




Fig. 8.1.1.7: Lime conversion cartridge

Cleaning the lime conversion cartridge

- ⇒ 1. The limescale conversion cartridge (1) is located on the right-hand side between the water guide and the center plate. To remove the cartridge, first detach the evaporation filter from the retaining lugs (3) and fold it slightly to the side.
- ⇒ 2. Pull off the pump hoses (2) and remove the lime conversion cartridge.



Fig. 8.1.1.8: Cleaning the lime conversion cartridge

- ⇒ 3. Check the passage of the cartridge for dirt. Remove contamination with the cleaning brush. If there is a lot of dirt, remove it with a screwdriver or drill (maximum diameter 7 mm).
- ⇒ 4. Attach the pump tubing to the lime conversion cartridge.
- ⇒ 5. Place the center section in the water tank.
- ⇒ 6. Thread the power cable through the opening in the housing and reattach the cable grommet. If necessary, connect the automatic water supply and the automatic flushing device.
- ⇒ 7. Close the side panel.
- ⇒ 8. Put on the upper part of the housing.



Make sure that the pump hoses are tight, otherwise water could leak out.

8.1.2 Replace UV lamp

The UV lamp is located under the center plate next to the pump motor. To replace it, proceed as follows:

NOTICE

Material damage due to incorrect touching of the UV lamp!

The UV lamp is very sensitive. Touching the glass body can greatly reduce its service life. Stains burn into the quartz glass and lead to early failures.

- Only touch the white end pieces of the UV lamp.
- Do not touch quartz glass with bare hands.
- Carefully remove stains with a clean cloth soaked in alcohol.
- Always remove the UV lamp slowly and carefully.

WARNING

Health hazard due to toxic mercury vapor!

The tube of the UV lamp contains toxic mercury. If the mercury vapors are inhaled, there is an acute danger of poisoning.

- When changing the UV lamp, always proceed carefully and do not damage the UV lamp.

CAUTION

Injury to the eyes due to ultraviolet radiation!

Unfiltered, direct and indirect UV radiation can cause damage to the skin and eyes.

- Never look into the light of the burning lamp.

WARNING




Danger of electric shock if the mains plug is not pulled out!



Staff: ▪ Operator

- ⇒ 1. Switch off the humidifier and unplug it from the mains.
- ⇒ 2. Lift the upper part of the humidifier housing upwards.

Fig. 8.1.2.1: Removing the upper part of the housing



- ⇒ 3. Open the side cover.
- ⇒ 4. Remove the cable gland (1) on the back of the unit and thread the power cable through the opening in the housing.
 - ➔ If necessary, disconnect the connections for the automatic water supply (2) and flushing device (3).




Fig. 8.1.2.2: Opening the side cover



- ⇒ 5. Lift the middle part of the humidifier out of the lower part of the unit and place it on its side.

Fig. 8.1.2.3: Remove centre part



Fig. 8.1.2.4: Disconnect connections

- ⇒ 6. Disconnect the tubes from the UV lamp housing.
- ⇒ 7. Remove the earth cable (2).




Fig. 8.1.2.5: Remove UV disinfection housing

- ⇒ 8. Remove the metal housing around the UV lamp. To do this, turn the metal tube anticlockwise. Then carefully pull off the housing.

⚠ WARNING

If the UV lamp inside the stainless-steel tube is damaged, toxic mercury vapors may escape!



Fig. 8.1.2.6: UV lamp in quartz glass tube.

- ⇒ 9. The UV lamp is in an additional quartz glass tube. Remove this by turning the bayonet catch counterclockwise (1). The glass tube can then be removed.



⚠ WARNING

If the quartz tube is damaged, glass fragments are produced which can cause cuts. Handle the component with care.




Fig. 8.1.2.7: UV lamp without quartz glass tube.

- ⇒ 10. Pull the UV lamp out of the connection socket (1). Only hold the UV lamp by the end pieces.
- ⇒ 11. Plug the new UV lamp into the four-pole connection socket (1).



Fig. 8.1.2.8: UV disinfection unit, complete

- ⇒ 12. The UV disinfection unit can now be reassembled. To do this, follow the steps in reverse order.

8.2 Automatic Water supply

Connecting the humidifier to the local water supply eliminates the need for manual filling. Refilling is done by an electronically controlled solenoid valve. This automatically opens the water supply when a minimum water level is reached and stops it as soon as the water tank is full. The unit is set to a maximum fill level of 30 litres (7.9 gallons). This means that when the fill level of 30 litres (7.9 gallons) is reached, the water supply is stopped.

The following additional accessories are recommended for safety:

- Safety catch basin
 - ↳ Chapter "8.4 Safety catch basin" on page 51
- Safety water sensor
 - ↳ Chapter "8.5 Safety water sensor" on page 51)
- External water monitor
 - ↳ Chapter "8.6 External water monitor" on page 51)

Operation

The water supply is controlled via the water level sensor of the water level indicator. For the water supply to function properly, it is therefore necessary to clean the water level sensor every month and remove any limescale deposits (↳ chapter '6.3.1 Monthly cleaning' on page 27).

Safety devices

To prevent overfilling, the appliance switches off automatically when the fill level reaches 30 liters (7.9 gallons). An acoustic warning signal sounds and the error message appears on the touch display. If the water supply is defective and the water level does not change after 10 minutes despite the solenoid valve being open, the process is aborted and the error message "Refill time" appears on the touch display.

Information for the sanitary specialist

Staff: ▪ Sanitation specialist

- ⇒ 1. To prevent contamination of the solenoid valve, flush the line thoroughly before connecting it.
- ⇒ 2. Connect the humidifier to the water supply system in accordance with the regulations of the local water supply company. Pay particular attention to the following points:
 - The material used or the connection must comply with the requirements of the IEC 61770 standard.
 - Only use new hoses. Hose sets that have already been used must not be reused.
 - Always observe the regulations of the local water supply company. A system separator may have to be used.
 - For a sketch with the dimensions of the connection see Fig. 8.3.1



Order numbers: 2606964

Requirements

- The automatic water supply is installed exclusively by the manufacturer. The connection to the local water supply system may only be carried out by an approved sanitary specialist.

⚠ WARNING

Risk of injury due to unauthorized connection of the humidifier to the local water supply system!

Connecting the humidifier to the local water supply system involves dangers that are not obvious to a layman.

- Only have the humidifier connected to the local water supply system by an authorized plumbing specialist.



The following information is intended exclusively for the sanitary specialist who connects the humidifier to the local water supply network.

NOTICE

Risk of property damage due to excessive water pressure!

If the water pressure of the local water supply network is too high, there is a risk that the humidifier will be damaged.

- The maximum water pressure must not exceed 1 MPa (145 Psi).

8.3 Automatic Flushing device

The automatic rinsing device is used to replace the residual water in the water tank at regular intervals and to add fresh water. It is only possible in combination with the automatic water supply; water exchange by hand is not necessary.



Order number: 2606965

Requirements


- Automatic water supply
- The installation of the automatic flushing device is carried out exclusively by the manufacturer. The connection to the local water supply system may only be carried out by an approved plumbing specialist.

Operation

The water exchange can be started manually. To do this, proceed as follows:






Staff: ▪ Operator

- ⇒ To start the rinse function manually, select the menu item "RINSE"  the main menu.
- ⇒ Press the "RINSE NOW!" button. The rinsing process begins.

In addition to starting manually, the flushing device can be programmed to automatically replace the water at intervals of 1-7 days. To do this, proceed as follows:


Staff: ▪ Operator

- ⇒ 1. Open the main menu .
- ⇒ 2. Open the menu item "RINSE" .
- ⇒ 3. Set the button "AUTOMATIC RINSE" to "ON"
- ⇒ 4. Change the value according to the desired interval.
- ⇒ 5. Confirm your entry with .

Information for the sanitary specialist

Staff: ▪ Sanitation specialist

- ⇒ Connect the automatic flushing device to the sewage system in accordance with the regulations of the local water supply company. Pay particular attention to the following points:
 - The material used or the connection must comply with the requirements of the IEC 61770 standard.
 - The waste water hose must not exceed a length of 150 cm, as only a certain pumping capacity is available and otherwise no pressure is built up.
 - Maximum delivery height of the flushing pump: 140 cm
 - Make sure that the waste water hose is not laid in an upward direction.
 - To build up the water column, if necessary, fill the hose with water before connecting it.
 - To prevent the formation of a vacuum, fit the line with a deaerator if necessary.
 - For a sketch with the dimensions of the connection, see Fig. 8.3.1.



NOTICE

Correct positioning of the drain hose

Pay attention to the minimum distance of the drain to the floor level. We recommend installing the drain at least 50 mm above the floor level. If the drain is set too low, there is a risk that the water tank will be drained and the automatic water supply will have to supply water permanently.

(1) Outlet automatic flushing device; (2) Inlet automatic water supply (AWS)

Fig. 8.3.1: Dimensional drawing for water connections

8.4 Safety catch basin




Fig. 8.4.1: Safety collection reservoir

The safety collection tray (1) is placed below the evaporative humidifier PureHum 1000 Pro. It catches the excess water in the event of a water leak.



Order number: 2606971

8.5 Safety water sensor



Abb. 8.5.1: Safety water sensor



Order number: 2139450

Requirements

- The safety water sensor is installed exclusively by the manufacturer.
- Safety catch basin

The safety water sensor is placed underneath the unit in the safety drip tray and reacts in case of an uncontrolled water leakage from the unit. The humidifier stops immediately and the user is notified of the water leakage by a beep and an error message on the touch display. As soon as the leaked water has been removed, the humidifier continues to run automatically.

8.6 External Water monitor



Fig. 8.6.1: External water monitor



Order number: 2593500

Requirements

- Automatic water supply
- Safety catch basin

With the automatic water supply of the humidifier, the external water monitor can be used as an additional safety device. In contrast to the safety water sensor, the water monitor has its own solenoid valve that is connected between the safety pressure hose and the water tap.

The sensor of the water detector is located in the safety drip tray and stops the water supply to the humidifier in case of water contact. In addition, a signal tone sounds which is only deactivated when the power supply is interrupted.

8.7 Wlan/Wifi


8.7.1 Wlan/Wifi Setup

Switch on the humidifier PureHum 1000 Pro, after a short time a new network should be visible. To do this, search the network environment on the PC or search for "Condair WLAN" under Network & Internet settings (mobile device) and connect to it:


The IP address 192.168.4.1 should now be displayed on the device.



Using a web browser, enter the IP address 192.168.4.1 as shown in the device and open the start page of the network setup.




Click on "Settings" to open a new menu for the WLAN configuration.



- 1.) The mode must be changed from "Config" to "Client".
- 2.) Enter the name of your existing WLAN network in the SSID field.
- 3.) Enter the corresponding password for your WLAN network in the PWD field.

Finally, transfer all entries to the device with "Apply".

The device now connects to the existing WLAN and receives a new IP address. It can now be controlled with the Condair PureHum APP (available for iOS and Android) or in the remote portal.



Newly obtained IP address from your network; process thus successfully completed. The humidifier PureHum 1000 Pro is now ready for use.

8.7.2 Condair PureHum App

The humidifier PureHum 1000 Pro can now be controlled with the Condair PureHum App (available free of charge for Android and iOS).



Condair PureHum

Produktivität

Laden

Condair Group AG

Produktivität




8.7.3 Activate Condair WLAN / reset network settings

Press and hold the Settings button for 10 seconds. In the Network field, a counter counts down to 0. The Condair WLAN is then activated and the network settings are reset.

ATTENTION!

Once the countdown is complete, all settings of the WLAN/WiFi module are deleted.

To enable operation of the device via the remote portal, you must log in at <https://condair.remoteportal.de>. To do this, enter the enclosed MAC address (see enclosed sticker) and the password below in the login window.



Anmelden


Benutzername oder MAC-Adresse:

Passwort:

automatische Anmeldung

Anmelden

The start page of the remote portal opens and a configuration can be made.



After registering, you can use the remote portal free of charge for 30 days via a trial account.

9. Spare parts

Order spare parts

Spare parts can be ordered from your local specialist dealer or directly from the manufacturer. For order numbers, see ↗ chapter "Appendix" on page 58.

⚠ WARNING

Risk of injury due to the use of incorrect spare parts!

The use of incorrect or faulty spare parts can be dangerous for the user and cause damage, malfunctions or total failure.

- Only use original spare parts from Condair Ltd. or spare parts approved by Condair Ltd..
- If you are unsure, always contact our service department.

9.1 Filter overview

Various evaporation and cleaning filters are available for the PureHum 1000 Pro.

Designation	Order number
BIO evaporation filter	2139320
Foam evaporation filter	2139322
Activated carbon cleaning filter	2606967
Fine dust filter set F7 (humidifier)	2606966
Hepa Filter Set H10 (air purifier)	2606968

10. Dispose of humidifier

Unless a take-back or disposal agreement has been made, disassembled components should be recycled:

- Scrap metals.
- Give plastic elements for recycling.
- Dispose of batteries and UV tube as special waste.
- Dispose of remaining components sorted according to material composition.

NOTICE

Danger to the environment due to incorrect disposal!

Incorrect disposal can be hazardous to the environment.



- Have electrical waste and electronic components disposed of by authorized specialist companies.
- In case of doubt, obtain information on environmentally sound disposal from the local municipal authority or specialized disposal companies.

11. Technical Data

11.1 Dimensions and Weight

Indication	Value	Unit
Unladen weight	28 / 61.73	kg / lbs.
Wide	850 / 33,47	mm / in
Height	630 / 25,24	mm / in
Depth	390 / 15,35	mm / in
Water tank volume	50 / 13.2	l / US gal

11.2 Connection values

Electric

Indication	Value	Unit
Voltage	115	V
Frequency	60	Hz
Power consumption, maximum (with special equipment)	115	W
Hedging, at least	10	W
Maximum water pressure when connected to the water supply network	145/1	psi /MPa
Minimum water pressure for connection to the water supply network	0	MPa

11.3 Operating conditions

Surroundings

Indication	Value	Unit
Temperature range	10 - 40 / 50 - 104	°C / °F
Relative humidity	30 - 90	%

11.4 Nameplate




Fig. 11.6.1: Type plate

The type plate is located under the upper part of the housing above the mains connection and contains the following information:

- Manufacturer
- Type
- Series
- Serial number

Appendix

- "Spare parts list" on page 59

▲ WARNING

Risk of injury from disassembling the humidifier!


The following illustration and parts list are intended exclusively for the specialist dealer. Unauthorized disassembly of the humidifier can lead to serious injuries.

- Never disassemble the appliance on your own.
- Only carry out the repairs described in the instructions independently.
- For all problems whose solution is not described in the instructions, contact the local specialist dealer.

Spare parts list

Standard version

No.	Naming
2606973	Upper part of housing (1)
2606972	Glass top incl. hinges (2)
2606985	Basic board
2139443	Pump complete (3)
2139444	Pump motor incl. cable and pump fan
2606977	Housing lower part/water tank (4)
2606981	Swivel castor
2139438	Filter rods without rib (5)
2139439	Filter rods with rib (6)
2139440	Clamp with 2 lugs (7)
2606987	Fan complete with motor, protective grille and fixing material (8)
2139437	Water distribution (9)
2139430	Radio humidity sensor (10)
2139448	Y-piece (11)
2139449	Pump hose transparent (12)
2606995	Corrugated tube 10 mm / 24 cm long for UV technology (13)
2606986	Level sensor
2139433	Mains cable with plug
2606672	Retaining rubber for cleaning filter
2606974	Intake grille



Special equipment and accessories

No.	Naming
2593500	Water detector with sensor
2139450	Safety water sensor
2606964	Automatic water supply complete
2606996	Solenoid valve complete
2606969	8-watt radiator (UV disinfection)
2606990	Quartz dip pipe
2139457	Lime conversion cartridge
2606997	Supply hose (100 cm)
2607000	Pump for flushing device
2606970	Drain hose for flushing unit (100 cm)
2606980	Water connection Housing lower part
2606971	Safety drip tray

Filters & Filter Sets

No.	Naming
2139322	Foam filter
2139320	Bio-Filter
2606966	Fine dust filter set F7 (humidifier)
2606968	Hepa Filter Set H10 (air purifier)
2606967	Activated carbon cleaning filter

Warranty

Condair Inc. or Condair Ltd. (depending on the entity that supplied the product, and hereinafter collectively referred to as CONDAIR) warrant for a period of two years after installation or 30 months from the manufacturer's ship date, whichever date is earlier, that CONDAIR's manufactured and assembled products, not otherwise expressly warranted, are free from defects in materials and workmanship. Notwithstanding the foregoing, the products listed below have an alternate warranty period:

- GS/GSTC Series heat exchanger(s) are warranted to be free from defects in materials and workmanship for a period of 3 years from installation or 40 months from the manufacturer's ship date, whichever is earlier.
- SAM-e Short Absorption Manifolds, except for the coupling seals, are warranted to be free from defects in materials and workmanship for a total period of 10 years from the manufacturer's ship date.
- Humilife RH humidifiers are warranted to be free from defects in materials and workmanship for a period of 5 years from the manufacturer's ship date. CONDAIR may, at its discretion, replace individual components or Humilife RH units as a whole.
- Spare Parts used for repairs are warranted for the balance of the term of the warranty on the original humidifier or 90 days, whichever is longer.
- No warranty is made against corrosion, deterioration, or suitability of substituted materials used as a result of compliance with government regulations.

CONDAIR's obligations and liabilities under this warranty are limited to furnishing replacement parts to the customer, F.O.B. CONDAIR's factory. The replacement parts are warranted for the balance of the term of the warranty on the original humidifier or 90 days, whichever is longer. Procedure:

1. Customer Requests Warranty as per instructions on the CONDAIR Warranty Form.
2. CONDAIR reviews the warranty claim and will respond in one of two ways:
 - a. Warranty Accepted – Replacement Part or credit granted.
 - b. Warranty Declined – Response with justification will be provided to the customer.
3. In some cases, CONDAIR may request the part to be returned, freight prepaid by the customer, as part of the warranty acceptance or warranty determination process. Some reasons include:
 - a. Part must be analyzed to determine the root cause of failure.
 - b. Part must be returned to the supplier for claim/investigation.

When parts are requested to be returned, replacement parts will be sent by CONDAIR to the customer against an invoice from CONDAIR paid by the customer. The cost of the replacement parts will be reimbursed to the customer with a credit note after the parts are received and analyzed by CONDAIR, if the warranty is accepted.

The warranties set forth herein are in lieu of all other warranties expressed or implied by law. No liability whatsoever shall be attached to CONDAIR until said products have been paid for in full and then said liability shall be limited to the original purchase price for the product. Any further warranty, with the exception of a purchased extended warranty described below, must be in writing, and signed by an officer of CONDAIR.

CONDAIR makes no warranty and assumes no liability unless the equipment is installed in strict accordance with the installation manual in effect at the date of purchase, and by properly qualified and licensed professionals capable of installing such equipment.

CONDAIR makes no warranty and assumes no liability whatsoever for consequential damage or damage resulting directly from misapplication, incorrect sizing, or lack of proper maintenance of the equipment.

CONDAIR makes no warranty and assumes no liability whatsoever for damage to the products, humidifier, supply lines, drain lines, steam distribution systems, or the building as a whole caused by freezing.

CONDAIR reserves the right to change the design, specifications, and performance criteria of its products without notice or obligation.

Extended Warranty

Extended warranties are available to purchase under the conditions listed above. Extended warranties must be purchased at the time of the original equipment order.

